DECO BREEZE®

10" Deco Table Top Fan



READ AND SAVE THESE INSTRUCTION

Instruction Manual

Overview of Functions

Please read the following instructions carefully and retain a copy of this information for future reference. When using this or any electrical appliance, the following safety precautions should be strictly followed:

Safety & Warnings

1. Use the fan only for the specific purpose outlined in this instruction information.
2. Do not operate fan until fully assembled.
3. Ensure the correct voltage is being used prior to plugging in your fan (120V AC Electrical Outlet).
4. Unplug fan from outlet when not in use, when changing locations, before assembly or disassembly, or prior to cleaning.
5. Do not immerse fan or expose fan to any form of liquid.
6. Avoid contact with all moving parts. Never insert your fingers, pencils or other objects through the fan grill during operation.
7. Place your fan on a stable and level surface to avoid tipping or being knocked over accidentally.
8. Do not operate the fan directly adjacent to curtains, plants, window coverings, etc. to avoid accidental entanglement.
9. For indoor household use only. Do not use outdoors or for industrial or commercial purposes.
10. To avoid potential fire hazards, never place your fan or its electrical cord under rugs, or carpeting.
11. Place the electrical cord away from busy areas to avoid accidental tripping and contact.
12. Always insert or remove plug from the outlet by grabbing the plug by hand. Do not pull on the electrical cord.
13. Never operate your fan near an open flame or in the presence of explosive or combustible gases or fumes.
14. Should your fan (including the electrical cord) ever become damaged or a malfunction occurs, discontinue operation at once until a certified repair has been made.
15. Do not expose your fan to excessive heat or humidity, as this can cause damage to the electrical components.
16. Keep your fan out of the reach of children and pets.
17. Do not expose infants or seniors to prolonged periods of direct cold air.

Fan Assembly

1. Carefully unpack the fan base and assembled motor head and fan grill from the Styrofoam packing cradle.
2. Remove Black Locking Screw from neck piece
3. Align fan head neck piece with stationary screw on fan base neck piece. Slide down until the neck piece slot and screw hole in the fan base neck piece align.
4. Reattach the Black Locking Screw to secure fan head to fan bse unit.



5. The last step is to connect the male power plug located on the back of the fan motor housing to the corresponding female plug located on the back of the neck at the top of the fan base. These must be joined for the fan to operate when the cord end is plugged into the power outlet.
6. You are now ready to enjoy your fan!



Fan Use

1. The speed selector switch is located on the back of the motor housing. To operate, simply twist the knob to the desired setting. Your fan features 3 speed settings (I – Lowest Speed, II – Medium Speed, III – Highest Speed). 0 – Fan is turned off.
2. The fan can operate in a stationary or an oscillating mode. To shift between modes, simply pull up or depress the Oscillation Button located next to the speed switch on the fan motor.
3. You can adjust the angle of your fan by adjusting the tilt adjustment screw underneath the fan motor at the base. Be sure to firmly tighten the screw when the desired angle is achieved.

Care & Cleaning

1. Always turn your fan to the off position prior to cleaning.
2. Clean parts with a duster or damp cloth. Prior to resuming use, make sure all moisture is dry.
3. Do not immerse in any type of liquid or use abrasive cleaning solutions.
4. Use care around the motor housing as no excessive moisture or liquid should come in contact with the motor housing or its parts.
5. When storing your fan, make sure to place in a dry environment. To reduce dust and particle exposure, it is best to cover your fan – especially in the off-season period.

Warranty Information

One (1) Year Limited Warranty

Service instructions: **DO NOT** attempt to repair or modify any mechanical or electrical parts of this fan. Doing so will void this warranty.

1. This Warranty applies ONLY to the original owner of this product.
2. This Warranty applies ONLY to the repair or replacement of any manufactured parts of this fan unit. Global Product Resources, Inc. reserves the right to determine if repair or replacement is warranted.
3. Operating the fan under conditions or usage not specified in the warnings, instructions, or care directions, or attempts to repair or modify the fan in anyway will render this Warranty void.
4. Unless otherwise prescribed by law, Global Product Resources, Inc. will not be liable for any personal injury, property or any incidental or consequential damage of any kind (including water damage) resulting from misuse, defects, malfunctions, improper installation or alterations of this product.
5. All parts of this product are guaranteed for a period of one (1) year from the date of purchase as follows.
6. If you experience any other problem or claim with this product, please contact our customer service department at (800) 979-4FAN.

Return Instructions

Please follow the directions below when initiating a Warranty Return:

1. Please pack your fan in its original carton or other carton and packing materials to insure no additional damage occurs in shipping.
2. Please include your full name, address with zip code and telephone number.
3. Additionally, please include a copy of your original sales receipt or Proof of Purchase.
4. Please also include a summary of the defect or problem that is occurring with the unit.
5. All shipping charges to be paid by the sender.
6. Call (800) 979-4326 for return authorization.

This warranty gives you specific legal rights, and you may have other rights which vary from state to state. The provisions of this Warranty are in addition to, and not a modification of, or subtraction from, the statutory warranties and other rights and remedies contained in any applicable legislation. To the extent that any provision of this Warranty is consistent with any applicable law, such provision shall be deemed voided or amended, as necessary, to comply with such law.

Deco Breeze is a trademark of Global Product Resources, Inc.